



Assembly Instruction






ITEM NO.:

H O M E L E G A N C E

8378BLK-4/BRW-4/GRY-4/WHT-4 OTTOMAN


NOTE: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.

COMPONENT LIST


NO.	DRAWING	QTY	DESCRIPTION
A		4	METAL LEG
B		8	WASHER
C		1	ALLEN KEY
D		8	BOLT
I		1	OTTOMAN




Legs and hardware are stored at the bottom of the ottoman, please take out for assembly.



Step 1 Align the legs to the pre-drilled holes at the bottom of the units, insert bolts and washers then tighten with Allen Key.



Step 2



Care instruction for PU surface furniture.

In order to maintain the original appearance of your PU surface furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and/or exposure to heating and air conditioning outlets will fade/damage PU. Do not place your PU surface furniture too close to windows, radiators, or vents, and be sure to use windows, radiators, or vents.
- Vacuum or wipe with a cloth regularly to remove dust.
- Clean PU surface furniture with professional cleanser.



For items use on wooden floor, hard surfaces or carpets, it is recommended to install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.